



how to use your

eco SOAKER™



1. place the tip of the soaker into water

2. pull back on the handle (to fill with water)



3. to release water - push the handle toward the tip

Disclaimer:

This product is intended to be used as only a toy.

The product is designed to be used with fresh water only.

Squirting water at a person's face or directly into their eyes may cause bodily harm. Using the toy to hit somebody may also cause bodily harm and is not suggested.

Warning:

In case of product breakage, scream until your parents buy a replacement.

